



# INSTRUCTIONS

Thank you for shopping at Car Builders.

In the table below, you can see where we have allocated individual products in the Troopy Packs. Below the table, we also have some product tips. Another helpful resource is our YouTube video where we install this pack '[Sound Deadening a Toyota Land Cruiser Troopy](#)'



QR for video of install

For further questions or concerns, please contact us 03 8777 0960

*\*Please ensure you follow the allocation table for the pack you purchased*

## **Pack 1-** Troopy Floor Pan, Quarter Panels and Doors Pack

	Front Floor (Firewall to under front seat)	Rear Quarter Panels	Rear Wheel Arches	Doors (incl. rear door/s)	Cargo Area	Roof
Sound Deadener	1 box	9 sheets	6 sheets	9 sheets	-	-
Waterproof Underlay	2 boxes	-	-	-	-	-
Aluminium Tape	This will be used to border Sound Deadener in the quarter panels and doors					

## **Pack 2-** Troopy *Premium* Floor Pan, Quarter Panels and Doors Pack

	Front Floor Pan (Firewall to under front seat)	Rear Quarter Panels	Rear Wheel Arches	Doors (incl. rear door/s)	Cargo Area	Roof
Sound Deadener	1 box	9 sheets	6 sheets	9 sheets	-	-
Mass Noise Liner Lite	Sheets	-	-	-	-	-
Mass Noise Liner	-	-	-	-	Sheets	-
Aluminium Tape	This will be used to border Sound Deadener in the quarter panels and doors					

## **Troopy Roof Pack**

	Floor Pan	Quarter Panel/Wheel Arches	Doors (incl. rear door/s)	Cargo Area	Roof
Sound Deadener					2 boxes
Aluminium Tape	This will be used to border Sound Deadener in the roof.				

## **Tips:**

### ***Sound Deadener:***

Ensure the surface is clean using a white-based spirit. Map out the allocated Sound Deadener to visualise coverage. Lay the sheet on the surface to assess if/how it needs to be cut to fit in planned area. Reveal the backing of the Sound Deadener. Place an end on the surface and slowly lay it down in a rolling motion until the sheet is laying on the surface. Do not pull the deadener over any depression in the surface, rather feed it down into the valley. Use your application roller to apply moderate pressure evenly across the total surface. Use the handle of the roller to apply pressure in valley areas. Sheets can abut or slightly overlap. There may be sections with gaps between sheets. There is no need to apply to mounts, top hats, cross members etc (you are aiming to cover single sheet metal panels). Ensure you leave clearance for bolt down points and areas that require future access.

### ***Waterproof Underlay / Insul-Layer:***

Both foams are a peel and stick product. It is important to lay the foam down and carefully template the area it will cover before revealing the backing film. Ensure you have enough material to account for rises and falls in the shape you're applying it to. Once you have the template cut out, reveal one end of the product and line it up on the surface. Then slowly reveal the backing while rolling the material onto the surface, **ensuring you aren't stretching the product**, rather try to slightly compress the material. This is particularly important when rolling the material into depressions in the sheet metal. If you stretch the material over and then try to push it into a depression, the material will fight to pop back up. Use the application roller to apply a moderate pressure evenly across the total surface. If you happen to get an air pocket under the material, you can prick through the material to release the air and use the roller to press it down.

### ***Mass Noise Liner / Mass Noise Liner Lite / Floor Mat***

This product is not a peel and stick product. It will sit under its own weight on the floor pan. It is important to lay the product down and carefully template the area it will cover, allowing for rises and falls in the floor pan. We have several tips and tricks in templating this product in vehicle installs on our YouTube channel.

**We would love to see your project and photos/video of your pack installed. Tag us in your social media so that we can give you a shout out on our social platforms.**

