



Thank you for shopping at Car Builders.

Now for the install...

In the table below, you can see where we have allocated individual products in the Single Cab Packs. Below the table, we also have some product tips. Another helpful resource is our YouTube video where we install this pack ['Sound Deadening a Single Pack'](#)



For further questions or concerns, please contact us on 03 8777 0960

QR for video
of install

**Please ensure you follow the allocation table for the pack you purchased*

Pack 1- 4x4 Single Cab Floor Pan and Rear Fire Wall Pack

	Floor Pan	Rear Fire wall	Doors	Roof
Sound Deadener	2 boxes			
Waterproof Underlay	2 boxes			
Aluminium Tape	This will be used to border Sound Deadener on the rear firewall.			

Pack 2- 4x4 Single Cab Floor Pan, Rear Fire Wall, Doors and Roof Pack

	Floor Pan	Rear Fire wall	Doors	Roof
Sound Deadener	2 boxes		1 box	
Waterproof Underlay	2 boxes			
Insul Layer				1 sheet
Aluminium Tape	This will be used to border Sound Deadener in the doors and the roof.			

Pack 3- 4x4 Single Cab Floor Pan and Rear Fire Wall Premium Pack

	Floor Pan	Rear Fire wall	Doors	Roof
Sound Deadener	2 boxes			
Mass Noise Liner	2 Sheets			
Acoustic Liner		1 box	You can use left-over from rear fire wall over Sound Deadener behind speakers in doors. See YouTube clip, 'Sound Quality in Doors: Deadener or Foam'	
Aluminium Tape	This will be used to border Sound Deadener on the rear firewall.			

Pack 4- 4x4 Single Cab Floor Pan, Rear Fire Wall, Doors and Roof *Premium Pack*

	Floor Pan	Rear Fire wall	Doors	Roof
Sound Deadener	2 boxes		1 box	
Mass Noise Liner	2 Sheets			
Acoustic Liner		1 box	You can use left-over from rear fire wall over Sound Deadener behind speakers in doors. See YouTube clip, ‘Sound Quality in Doors: Deadener or Foam’	
Insul Layer				1 Sheet
Aluminium Tape	This will be used to border Sound Deadener in the doors and the roof.			

Tips:

Sound Deadener:

Ensure the surface is clean using a white-based spirit. Map out the allocated Sound Deadener to visualise coverage. Lay the sheet on the surface to assess if/how it needs to be cut to fit in planned area. Reveal the backing of the Sound Deadener. Place an end on the surface and slowly lay it down in a rolling motion until the sheet is laying on the surface. Do not pull the deadener over any depression in the surface, rather feed it down into the valley. Use your application roller to apply moderate pressure evenly across the total surface. Use the handle of the roller to apply pressure in valley areas. Sheets can abut or slightly overlap. There may be sections with gaps between sheets. There is no need to apply to mounts, top hats, cross members etc (you are aiming to cover single sheet metal panels). Ensure you leave clearance for bolt down points and areas that require future access.

Water Proof/ Rear Firewall Foam /Insul Layer:

Each of these foams are a peel and stick product. It is important to lay the product down and carefully template the area it will cover before revealing the backing film. Ensure you have enough material to account for rises and falls in the shape your applying it to. Once you have the template cut out, reveal one end of the product and line it up on the surface. Then slowly reveal the backing while rolling the material onto the surface, **ensuring you aren't stretching the product**, rather try to slightly compress the material. This is particularly important when rolling the material into depressions in the sheet metal. If you stretch the material over and then try to push it into a depression, the material will fight to pop back up. Use the application roller to apply a moderate pressure evenly across the total surface. If you happen to get an air pocket under the material, you can prick through the material to release the air and use the roller to press it down.

Mass Noise Liner

This product is not a peel and stick product. It will sit under its own weight on the floor pan. It is important to lay the product down and carefully template the area it will cover, allowing for rises and falls in the floor pan. We have several tips and trick in templating this product in vehicle installs on our YouTube channel.

We would love to see your project and photos/video of your pack installed. Tag us in your social media so that we can give you a shout out on our social platforms.

